



Banquet Carts - Plate Capacity


While our banquet carts have standard capacities, you may have a plate size that is larger or smaller than the range listed on our specifications. Because there is such a variety of plate sizes and cover heights, use the capacities listed in the specifications as a general rule, not the final word.

HOW TO ACCURATELY FIGURE BANQUET CART CAPACITY:

EASY AS 1-2-3: Reference the clearance between shelves and the shelf length and depth in the tables on our catalog product pages.

- 1) Stack plates with covers 4 or 5 high and measure the height of the entire stack.
- 2) Then, determine how many in a stack will fit in the space between the shelves.
- 3) Next, figure out how many stacks of plates you can fit within the dimensions of the shelf size. **NOTE:** If you have large plates and are considering a smaller cart, stacks can be staggered for the best use of space.

Cart Capacity = number of plates per stack x number of stacks per shelf x number of shelves in cart



Banquet Carts - Plate Capacity Guide

The tables for our models on our specifications list capacities for common plate sizes with a standard cover height of 2.5". If you have a different plate diameter, the chart below can be used as a guide to find approximate plate capacity.

	Model Number	Plates per Stack	Number of Shelves	Diameter of plate with cover (inches)								
				10 ½	10 ¾	11	11 ¼	11 ½	12	12 ¼	12 ½	12 ¾
EquaHeat	BB700	5	3	60	60	60	60	45	45	45	30	30
	BB1100	4	3	96	96	96	96	96	72	60	60	60
	BB1300	5	3	120	120	120	120	120	90	75	75	75
	BB1600	5	3	150	150	150	135	135	120	120	105	105
	BB1300XX	5	3	180	150	150	150	150	150	150	150	120
Classic Carters	BB40	6	2	48	48	48	48	48	36	24	24	24
	BB48	5	3	60	60	60	60	60	45	30	30	30
	BB60	5	2	72	72	60	60	48	48	48	48	36
	BB64	5	4	80	80	80	80	80	60	60	60	60
	BB72	5	3	90	90	75	75	60	60	60	60	45
	BB90	3	5	90	75	75	75	75	60	60	45	45
	BB96/BB96E	5	3	120	120	105	90	90	90	75	75	75
	BB100	5	4	120	120	120	120	100	100	100	80	80
	BB120/BB120E	6	3	144	126	126	108	108	90	90	72	72
	BB150/BB150E	6	3	180	162	162	144	144	144	126	108	108
	BB200D	5	4	200	200	180	180	160	160	120	120	100
	BB96X	5	3	120	120	120	120	120	120	120	105	105
	BB120X	6	3	144	144	144	144	144	144	144	126	126
	BB150X	6	3	198	180	180	180	180	180	162	144	144
	BB96XX	5	3	135	135	135	135	120	120	120	120	120
BB120XX	6	3	162	162	162	162	144	144	144	144	144	
BB150XX	6	3	234	216	198	198	180	180	180	180	180	
Convertibles	BB1000	4	3	120	120	120	120	108	96	96	96	96
	BB1200	5	3	150	150	150	135	120	120	120	120	120
	BB1824	3	2	24	24	24	18	18	12	12	12	12
	BB1848	4	3	48	48	48	27	27	18	18	18	18
EnduraHeat	BB1864	4	4	64	64	64	36	36	24	24	24	24
	BR96	4	3	96	96	96	96	96	72	60	60	60
	BR120	5	3	120	120	120	120	120	90	75	75	75
	BR150	5	3	150	150	150	135	135	120	120	105	105
	BR1000	4	3	120	120	120	120	108	96	96	96	96

NOTE: Capacities based on common plate depth and combined plate/cover height of 2.5". Due to the wide variety of plate thicknesses and depths as well as plate cover heights, actual capacities may vary.